

Golden Touch Mop Assembly

Important Tips

To prevent the water reservoir from leaking during use, it is important to carefully observe the following steps when assembling the unit.

There are two pieces that slide in and out of the base of the unit; a **water canister** and a **water valve** that it fits into. The canister upon opening the box will be detached from the unit and the triangular piece will be attached. To begin, detach the triangular piece from the base so that both pieces are loose.

- 1) Slide the water valve into the base as shown, giving it a gentle push so that it lines up evenly with the base and the space between the piece and the base is minimal.
- 2) Locate the grooves on either side of the water canister and line them up with the grooves at the top of the water valve.
- 3) Place the water canister above the water valve and perpendicular to the base unit, then firmly push the canister straight down into the grooves and make sure it is locked firmly in place.

Ensuring proper assembly will prevent leaking – if the unit is not tightly assembled, you will notice water fill up just below the reservoir and leak out of the base of the unit. This can be corrected by disassembling the unit and re-assembling, as above.

